PUBLIC

Class: TN Doc. no: TERMA/SPD/63/T-EMU/DEV/

APBUART Rev: 1.0 Date: 2015-03-01

Approved by: Michela Alberti



T-EMU: GRLIB APBUART Device Model Manual



Prepared	Checked
Mattias Holm Technical Manager	Dan Søren Nielsen QA Manager
Approved	
Michela Alberti General Manager	

T-EMU: GRLIB APBUART Device Model

Manual

Doc. no: TERMA/SPD/63/T-EMU/DEV/

APBUART, Rev: 1.0



Record of Changes

Author	Description	Rev	Date
Mattias Holm	Initial Version	1.0	2015-03-01

Table of Contents

1.	Introduction	2
	Properties	
	Interfaces	
	Limitations	-

1. Introduction

The APBUART is part of the GRLIB device library from Gaisler. The ApbUart model supports both infinite speed UARTs (where bytes are sent when the register is written) and the emulation of FIFOs and send times based on the scaler.

2. Properties

pnp.config APB plug and play config word

pnp.bar APB plug and play bar register

config.infiniteUartSpeed Set to 1 to enable infinite UART speed.

config.fifoSize The FIFO size of the UART, set to 1 for FIFO free UARTs.

config.interrupt The interrupt this UART will raise.

data ApbUart data register. Writing to this will put a byte in the FIFO.

status Status register.

control Control register.

scaler Scaler register.

fifo_debug FIFO debug register (not supported).

tx Serial interface destination

queue EventIface (normally provided by the CPU or machine object)

irqCtrl IRQ controller that the UART should send IRQs to.

rxFifo.start Read location for Rx fifo

rxFifo.usage Current bytes in Rx fifo

PUBLIC

T-EMU: GRLIB APBUART Device Model

Manual

Doc. no: TERMA/SPD/63/T-EMU/DEV/

APBUART, Rev: 1.0



rxFifo.size Fifo size

rxFifo.data Fifo data buffer

txFifo.start Read location for Tx fifo

txFifo.usage Current bytes in Tx fifo

txFifo.size Fifo size

txFifo.data Fifo data buffer

txShift Shift register. Only used when UART speed is non-infinite.

3. Interfaces

MemAccessIface Type = MemAccessIface. Handles MMIOs.

UartIface Type = SerialIface. Serial interface for the receiver.

DeviceIface Type = DeviceIface.

ApbIface Type = ApbIface. PnP access interface.

4. Limitations

• Loop back mode is not presently supported.

• Control flow (cts) is not supported