

TEMU
GRCAN Model

Mattias Holm

Version 1.0, 2019-12-12

Table of Contents

1. Introduction	1
2. Loading the Plugin	1
3. Attributes	1
3.1. Properties	1
3.2. Interfaces	2
3.3. Ports	2
4. Registers	2
4.1. Register Bank default	2
4.1.1. Register cfg	2
4.1.2. Register stat	3
4.1.3. Register ctrl	3
4.1.4. Register syncMaskFilt	3
4.1.5. Register syncCodeFilt	3
4.1.6. Register pendIrq	3
4.1.7. Register irqMask	4
4.1.8. Register txChanCtrl	4
4.1.9. Register txChanAddr	4
4.1.10. Register txChanSize	4
4.1.11. Register txChanWr	5
4.1.12. Register txChanRd	5
4.1.13. Register txChanIrq	5
4.1.14. Register rxChanCtrl	5
4.1.15. Register rxChanAddr	6
4.1.16. Register rxChanSize	6
4.1.17. Register rxChanWr	6
4.1.18. Register rxChanRd	6
4.1.19. Register rxChanIrq	6
4.1.20. Register rxChanMask	7
4.1.21. Register rxChanCode	7
5. Limitations	7

1. Introduction

The GRCAN model is available in the GrCan plugin.

2. Loading the Plugin

```
import GrCan
```

3. Attributes

3.1. Properties

Name	Type	Description
bus	iref / CanBusIface	CAN bus
cfg	uint32_t	Configuration register
config.irq	uint8_t	Interrupt number
config.singleIrq	uint8_t	Single interrupt
ctrl	uint32_t	Control register
irqCtrl	iref / IrqCtrlIface	IRQ controller
irqMask	uint32_t	Interrupt register
mem	iref / MemoryIface	Memory
object.timeSource	object	Time source object (a cpu or machine object)
pendIrq	uint32_t	Pending interrupt register
rxChanAddr	uint32_t	RX channel address register
rxChanCode	uint32_t	RX channel code register
rxChanCtrl	uint32_t	RX channel control register
rxChanIrq	uint32_t	RX channel irq register
rxChanMask	uint32_t	RX channel mask register
rxChanRd	uint32_t	RX channel read register
rxChanSize	uint32_t	RX channel size register
rxChanWr	uint32_t	RX channel write register
stat	uint32_t	Status register
syncCodeFilt	uint32_t	SYNC code filter register

Name	Type	Description
syncMaskFilt	uint32_t	SYNC mask filter register
txChanAddr	uint32_t	TX channel address register
txChanCtrl	uint32_t	TX channel control register
txChanIrq	uint32_t	TX channel irq register
txChanRd	uint32_t	TX channel read register
txChanSize	uint32_t	TX channel size register
txChanWr	uint32_t	TX channel write register

3.2. Interfaces

Name	Type	Description
ApbIface	ApbIface	APB P&P interface
CanDevIface	CanDevIface	CAN device interface
MemAccessIface	MemAccessIface	Memory access interface (registers)

3.3. Ports

Prop	Iface	Description
-	-	-

4. Registers



Register support is currently experimental!

4.1. Register Bank default

4.1.1. Register cfg

Congifuation register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.2. Register stat

Status register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.3. Register ctrl

Control register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.4. Register syncMaskFilt

SYNC mask filter register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.5. Register syncCodeFilt

SYNC code filter register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.6. Register pendlrq

Pending interrupt register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.7. Register irqMask

Interrupt register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.8. Register txChanCtrl

TX channel control register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.9. Register txChanAddr

TX channel address register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.10. Register txChanSize

TX channel size register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.11. Register txChanWr

TX channel write register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.12. Register txChanRd

TX channel read register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.13. Register txChanIrq

TX channel irq register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.14. Register rxChanCtrl

RX channel control register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.15. Register rxChanAddr

RX channel address register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.16. Register rxChanSize

RX channel size register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.17. Register rxChanWr

RX channel write register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.18. Register rxChanRd

RX channel read register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.19. Register rxChanIrq

RX channel irq register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.20. Register rxChanMask

RX channel mask register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

4.1.21. Register rxChanCode

RX channel code register

Cold reset value: 0x0

Warm reset value: 0x0

Field	Mask	Cold	Warm	Description
-	-	-	-	-

5. Limitations

- None